











Turfware TR360 Operator's Manual

TABLE OF CONTENTS

	3 SAFETY
OVERVIEW	3
SAFETY SYMBOLS - IN THIS MANUAL	3
SAFETY LABELS - ON THE MACHINE	4
SAFETY LABELS - ON THE MACHINE	5
WARNINGS AND PRECAUTIONS	6
GENERAL SAFETY PRECAUTIONS	6
OPERATION PRECAUTIONS	6
OPERATION PRECAUTIONS CONT	7
FUEL PRECAUTIONS	7
ENGINE PRECAUTIONS	7
TIRE PRECAUTIONS	7
PRODUCT OVERVIEW	8-11
TR360 Use And Care	12
STARTING AND STOPPING THE TR360 ENGINE	12
SPREADER OPERATION	13
OPERATING THE SPREADER	13
CLEANING THE SPREADER—DAILY	14
SPRAYER OPERATION	14
OPERATING THE SPRAYER	15
CLEANING THE SPRAYER - DAILY/LONG TERM	15
GREASE MAINTENANCE	16
MAINTENANCE AND STORAGE - DAILY	17
HYDRAULIC SYSTEM MAINTENANCE - DAILY	17
WARRANTY INFORMATION	17
OPTIONAL COMPONENTS.	17
DUAL HOPPER SYSTEM	17
MAINTENANCE SCHEDULE	
MAINTENANCE CHART	19
SPECIFICATIONS - MODEL TR360	20
SPRAYING SYSTEMS NOZZLE SELECTION RATES	21
APPLICATION CALIBRATION RATES	22
SAFE WORK PROCEDURES	23

Introduction

Congratulations on the purchase of your TR360 ride-on spreader and sprayer from Turfware Equipment Company. We look forward to working with you and your organization to help meet your turf maintenance goals for years to come.

The TR360 Operator's Manual is part of this machine and must be available to the operator at all times. Store this manual in the Operator's Manual storage compartment located on the left side of the machine.

This manual provides you with the information you need to understand the safety requirements, operation, and features of the TR360 ride-on spreader and sprayer.

The TR360 should only be operated and maintained by thoroughly trained individuals. All operators and maintenance personnel are urged to read this entire manual for their personal safety, and to fully understand the machine operation.

Do not operate this machine unless all safety and warning labels are in place.

In addition to this manual, the Honda Owner's Manual is included separately with your machine. Refer to the Honda manual for more information about the care and servicing of the engine.

Safety Overview

The safety symbols shown in this manual and the safety labels located on the machine are used to draw attention to potential safety hazards.

Please read and follow all safety label instructions to avoid injury to yourself and others, and to prevent machine damage.

If you discover a machine safety label is damaged, missing or scratched, order a replacement immediately and do not operate the machine until the label has been replaced.

Safety Symbols - In this Manual

The safety symbols used in this manual are shown below.

The WARNING symbol used in this manual identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss.

The IMPORTANT symbol used in this manual identifies information that is critical for successful application and understanding of the product.









WARNING





NOTE: The engine manufacturer is responsible for all engine-related issues with regards to performance, power-rating, specifications, warranty and service. Please refer to the Honda Owner's Manual, included separately with your machine, for more information.

Safety Labels - On the Machine

Safety labels found on your TR360 are illustrated in this section. Always follow their instructions and heed their warnings.



A DANGER label indicates a hazardous situation that, if not avoided, will cause death or serious injury. For your safety, locate and become familiar with the hazardous areas of the machine.

The following Danger label is found on the dashboard. For your safety and protection, be sure to locate and become familiar with all the dangerous areas of the machine.



Figure 2: Dashboard Danger Label Example



A WARNING label indicates a hazardous situation that, if not avoided, could result in death or serious injury.



Figure 3: Dashboard Danger and Warning Label Examples

The following safety warning labels are found on the machine. For your protection, locate and become familiar with the hazardous areas of the machine.





The following safety labels are found on the machine. For your protection, locate and become familiar with the hazardous areas of the machine.







Warnings and Precautions

General Safety Precautions

- Read, understand and follow all instructions in this Operator's Manual, the Honda Owner's Manual, and on the machine before starting the machine.
- Become familiar with the safe operation of the equipment, operator controls and safety labels.
- All operators and maintenance personnel should be trained before using the equipment.
- Do not operate this machine while under the influence of alcohol or drugs.
- Never let children under the age of 18 years old or untrained people operate or service the equipment.
- Do not remove any shields, guards, labels or safety devices.
- Verify any shields, guards, labels or safety devices are in place and functioning properly. If needed, repair or replace it before operating the equipment.
- Never run the engine indoors or in an enclosed area without adequate ventilation. Exhaust fumes are extremely
 hazardous and can kill you.
- Exercise extreme caution when applying and handling chemicals. Chemicals can be dangerous; read the chemical
- MSDS (Material Safety Data Sheets) and container label for proper/safe handling instructions.
- Always wear safety glasses, long pants and safety shoes when operating or maintaining this equipment, and when applying and handling chemicals. Use protective measures as directed by the MSDS.
- Do not operate this equipment while under the influence of prescription medicines which may impair your coordination.

AWARNING

Operation Precautions

- Do not operate the machine unless all safety devices are functioning properly.
- Keep adults, children and pets away from the area to be managed.
- Before working, inspect the work area and remove debris and other objects that may interfere with the machine.
- Watch for holes, sprinkler heads and other hidden hazards.
- · Reduce speed when making turns.
- Use extra care when operating the machine with an empty hopper. This can affect the stability of the machine.
- Do not operate the machine on slopes exceeding 20 degrees.
- Do not operate the machine on steep slopes if you are uncertain about machine traction and stability.
- Do not operate the machine in wet or low light conditions.
- Slow down and use extra caution on hillsides. Go laterally or diagonally across the slope, not up and down the slope. Be aware that turf conditions can affect the machine's stability.
- Use caution while operating near drop-offs, ditches or embankments.
- Always have proper footing on slopes and hillsides, and never operate the machine when conditions are slippery. Be very careful on wet grass.
- Use care when approaching blind corners, shrubs, trees or other objects that may obstruct your vision.
- Do not operate in reverse unless absolutely necessary. Look behind and down before backing up to be sure the path is clear.
- Never carry passengers.
- Use care when loading or unloading the machine into a trailer or truck.
- Use care when crossing gravel paths or roadways.
- Always have your feet and hands clear of the controls when starting the engine.
- To avoid serious burns, do not touch the engine or muffler while the engine is running or until it has cooled for at least 30 minutes after it has been shut off.
- To prevent the engine from accidentally starting, always disconnect the spark plug wire before performing any maintenance on this machine.
- Keep the machine, and especially the engine/transmission area, clean and free of grease, grass and leaves to reduce the potential for overheating and fire.
- Do not exceed the hopper capacity of 250 lbs.







- Use extra care when handling gasoline and other fuels. Gasoline is highly flammable and vapors are explosive.
- Always stop the engine and allow it to cool before removing the fuel tank cap.
- Add fuel outdoors in an open area on level ground.
- Never add fuel while the engine is running.
- Never refuel or drain the machine indoors.
- When filling the fuel tank, stop when the gasoline reaches the maximum fuel level limit. Do not overfill to allow for expansion.
- Never use stale or contaminated gas.
- Never use an oil/gas mixture.
- Do not smoke or permit others to smoke while handling gasoline.
- Always use approved containers for gasoline.
- If the fuel container spout does not fit inside the fuel tank opening use a funnel. Wipe up any spilled gasoline immediately.



Refer to the Honda Owner's Manual, included separately with your machine, for more information about engine precautions.



Engine Precautions

- The engine exhaust emits toxic carbon monoxide gas. Do not run the engine in an enclosed area.
- Engine exhaust, some of its constituents and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.
- Allow the engine parts, especially the muffler, to cool before touching to avoid burns.

WARNING Tire

- **NG** Tire Precautions
- Before operating the machine check for worn tires. Tires with excessively worn tread are dangerous on slopes or inclines. Replace as needed.
- Always maintain the tire pressure at max PSI of 22 lbs. Do not under or over inflate the tires.





Product Overview



- 1 Spray On/Off Button
- 2 Hopper On/Off Levers
- 3 Drive Bar
- 4 Hopper Agitator Button
- 5 Spray Pressure Gauge
- 6 Spray Pattern Control; Narrow, Wide, Wand
- 7 Deflector Shield Handle
- 8 Spray Tank Filler Caps
- 9 Honda Engine
- 10 Parking Brake
- 11 Operator Platform







Product Overview Cont.







Product Overview cont.





- 23 Spray Pressure Regulator
- 24 Spray Nozzle Assembly
- 25 Spreader Impeller Unit
- 26 Deflector Shield





Product Overview cont.



26 - Spray System Pump27 - Spray System Filter Housing (2)



28 - Hopper Slide Shutoff and Flow Assembly29 - Spray Nozzle





TR360 Use & Care



Refer to the Honda Owner's Manual, included separately with your machine, for more information about engine pre-checks and starting/stopping the engine

Starting the TR360 Engine



Before starting the engine engage the parking brake to avoid injury.

NOTE: Refer to the **Honda Owner's Manual**, included separately with your machine, for more information about the fuel valve lever, choke lever and engine switch location.

- 1) Move the **Fuel Valve Lever** 1 to the ON position.
- 2) Start the engine:
 - a) For a cold engine move the **Choke Lever** (2) to the CLOSED position.
 - b) For a warm engine leave the choke lever in the OPEN position.
- 3) Move the **Throttle Lever** (3) away from the MIN position to about 1/3 of the way toward the MAX position.
- 4) Turn the engine switch to the ON position.
- 5) Operate the starter:



Tip: If the battery is dead use the recoil starter to start the engine. Make sure the key is in the run position.

- a) If using the recoil starter pull the pull cord toward you then return the pull cord gently.
- b) If using the electric starter key turn the key to the START position and hold it there until the engine starts. When the engine starts release the key, allowing it to return to the ON position.
- 6) If the choke lever is in the CLOSED position gradually move it to the OPEN position as the engine warms up.
- 7) Set the throttle level to control the engine speed. Do not exceed 3200 RPMs.

IMPORTANT To avoid injury always engage the drive bar slowly.

- 8) To move the machine:
 - a) Forward Pull the drive bar toward you.
 - b) Reverse Push the drive bar away from you.
 - c) Release the drive bar to return to neutral and stop the forward/reverse motion.

Stopping the TR360 Engine

- 1) Move the throttle lever to the MIN position.
- 2) Turn the engine switch to the OFF position.
- 3) Turn the fuel valve lever to the OFF position (when stored).

NOTE: To stop the engine in an emergency situation you can turn the engine switch to the OFF position





Spreader Operation

The spreader unit is designed to handle dry, clean, free-flowing granular material only.

IMPORTANT

Spreader calibration should be performed as an ongoing process throughout the day. Monitor material used versus area serviced and adjust accordingly. The application rate will vary throughout the application process. Factors affecting the calibration rate include product rate selector setting, ground speed of the unit, impeller speed and width of passes.

NOTE: The sprayer unit and the spreader unit can be operated at the same time to provide an even distribution of both the sprayed and spread products to an area.

Operating The Spreader

MPORTANT When spreading material fully engage the drive bar.

Refer to the TR360 Calibration Sheet for more information about the granular application.

- 1) Fill the hopper with material. Do not exceed the maximum hopper weight capacity of 250 lbs.
- 2) Set the engine to the recommended 2800 RPMs. Confirm with the hour/tachometer meter on the dashboard.
- 3) Adjust the **Product Rate Selector**, **1** located above the hopper lever, to match the material coverage you desire.

NOTE: The numbers are merely an indicator and have no bearing on material rate.

- **TIP:** For best results use a setting on the low side. If the setting proves to be too low cover the area again. Once the desired setting is determined a higher setting can be used.
- 4) Adjust the variable **Impeller Speed Control** (2) to achieve the desired fertilizer spread width. The impeller speed control knob will increase or decrease the spread width to your desired spread pattern.

NOTE: The spread pattern is independent of ground speed.

- 5) Monitor and adjust the product rate selector as needed to maintain accurate coverage of material. The product rate selector position determines the amount of material to be broadcast. The higher the number, the heavier the application of material.
- 6) Go to the spreading location.
- 7) Ensure the area to be maintained is clear.
- 8) Engage the drive bar fully when applying materials.
- 9) Push the hopper lever to the OPEN position.
- 10) Adjust the impeller speed control as needed.







Operating the Spreader cont.

- 11) Apply the granular material on 9-foot center passes. The outer edge of the fertilizer pattern should fall between the wheel tracks of your previous pass.
- 12) Evaluate the spread pattern:
 - a) If the spread pattern is good continue to spread at a recommended speed of 3 MPH.
 - b) Adjust the spread pattern as necessary.
- 13) When applicable, use the deflector shield to prevent granular material from being spread to the right side of the machine.

NOTE: When using the deflector be sure to reduce the fertilizer rate to avoid over fertilizing the area.

- 14) Move the hopper lever to the CLOSED position.
- 15) Clean the hopper after each day's use.

Cleaning the Spreader - Daily

Always empty and properly clean the spreader unit immediately after each use.

- 1) Drive the machine to a designated cleaning area.
- 2) Stop the machine on a level surface, turn off the engine and engage the parking brake.
- 3) Empty the contents of the hopper and place the material into the original bag for future use.
- 4) Using a garden hose, spray the inside and outside of the entire spreader with clean water.

▲ IMPORTANT

Use caution when using a power washer to clean the machine. The high pressure water may force residual corrosive materials into other parts of the spreader and sprayer units.

5) Allow the machine to dry completely before the next use.

Sprayer Operation

The sprayer unit is designed to disperse liquid materials only.

NOTE: The sprayer unit and the spreader unit can be operated at the same time to provide an even distribution of both the sprayed and spread products to an area.

Refer to the TR360 Calibration Sheet for more information about the liquid application.





Operating the Sprayer

IMPORTANT

The spray system is not for use with wettable powders or water dispersible granules. All materials must be in liquid form and premixed prior to adding them to the tank.

- 1) Make sure the machine is on level ground and apply the parking brake.
- 2) Open the tank cap on the spray tank and fill the tank with the pre-mixed liquid.

NOTE: Make sure the tank is half full before priming the spray system.

- 3) Go to the work area.
- 4) Ensure the area to be maintained is clear.
- 5) Select the appropriate spray pattern: wide, narrow or wand.
 - a) To spray using the front sprayer nozzles:
 - i) Choose the Wide or Narrow control.
 - ii) Press the spray button on the left handlebar to apply the solution to the work area.
 - b) To use the spray wand:
 - i) Remove the wand from the holder.
 - ii) Choose the **Wand** control.
 - iii) Hold the spray wand and point it in the direction to be sprayed.
 - iv) Squeeze the spray wand trigger to begin spraying.
- 6) Empty and clean the sprayer.

Cleaning the Sprayer—Daily/Long Term

Always empty and properly clean the sprayer unit immediately after each use and prior to storage.

- 1) Spray all contents onto a turf area until the spray system is empty.
- 2) Fill the tank with fresh water.
- 3) Spray all contents onto a turf area again through the wide nozzle, narrow nozzle and spray wand until fresh water flows through each. Repeat this cleaning process three times to ensure complete rinsing of the spray system.
- 4) Remove, clean, and inspect the three nozzle screens located in the spray nozzle bodies and the main spray system filter. Replace if necessary. When cleaning the screen be sure the screen housing GASKET remains in place. The spray system will not build pressure without the gasket.
- 5) For long-term storage in freezing conditions add an RV type of anti-freeze and cycle it completely through the spray system.

Refer to the Honda Owner's Manual, included separately with your machine, for more information about proper long-term storage of the engine. MAINTENANCE AND STORAGE - DAILY





Grease Maintenance

There are only 3 Grease Fittings that require WEEKLY Grease on the TR360.

THIS IS THE SINGLE MOST IMPORTANT CARE POINT FOR YOU TO FOCUS EFFORT ON. Grease is like preventative medicine. Liberal use of grease and care of the machines needs will prevent major costly issues.

It is always better to over grease than under grease. FAILURE TO GREASE THE PIVOT AND FRONT AXLE WILL **RESULT IN FAILURE AND EXPENSIVE REPAIR.** We do everything possible to utilize the best taper bearings, seals, and other wear items to prevent wear and provide long life. Please do your part!

You can ensure years of uninterrupted life from your TR360 by simple greasing the Front Axle and adjusting and greasing the Pivot Point.



Pivot Point (1 Grease Fitting)

After the first 50 Hours of use (break in period) adjust the Pivot Point. Remove the Cotter Pin at the base of the Pivot Point Spindle. Tighten (CW Turn) the Castle Nut and replace the Cotter Pin back in the Spindle. GREASE the Pivot Point Heavily. Repeat this as necessary to keep tension on the Pivot Point and reduce sloppiness from being felt in the **Operator Steering Bar (Handle).**

KEEP THE PIVOT POINT GREASED ON GOING! AT LEAST WEEKLY.

Front Axle (1 Grease Fitting each side of the Spreader)

Grease the Fittings on the inside of the Front Wheel Hubs WEEKLY!



Inner Wheel Hub



Pivot Point Grease Fitting

Front Axle





Maintenance and Storage - Daily

- 1) Clean the entire spreader completely.
- 2) Inspect the entire spreader and pay special attention to any worn parts.
- 3) Inspect the pivot point. Grease and adjust the castle nut as needed.
- 4) Check all fluid levels and inspect hoses and fittings for leaks.
- 5) Check the hydraulic pump, Lovejoy coupling and cables for fit, wear and alignment. Make the appropriate adjustments or repairs.

Hydraulic System Maintenance - Daily

- 1) Check the hydraulic reservoir oil level.
 - Use 5w-30 oil.
 - Bring the level up to the return line on the front of the reservoir.
- 2) Check the entire hydraulic system for leaks and make necessary adjustments.
- 3) If you need to push or tow the TR360, use the tow valve on top of the hydraulic pump. (A hex head with a hole running through it.) Turn the hex head counter-clockwise 1 to 2 turns. This opens the hydraulic system and allows for easy rolling. Remember to re-tighten the valve to resume operating.

Warranty Information

Refer to the Maintenance Schedule on page 19 for yearly hydraulic system maintenance tasks.

Optional Components

Dual Hopper System

The dual hopper is an option that can be added to your TR360 at any time. The purpose of the dual hopper is to allow you the convenience of having two dry materials on board with you at all times.

The flow is controlled by either the front hopper on/off lever or the rear on/off lever, depending on which material you wish to apply.

Refer to the Spreader Operation section on page 13 for more details.



Dual Hopper System

Contact Turfware Equipment Company for more information about this optional feature.



Maintenance Record

Refer to the Honda Owner's Manual, included separately with your machine, for detailed information about engine maintenance procedures and maintenance intervals.

Maintenance Chart

	Honda Engine	Drive System	Wheels and Tires	Pivot Point	Front Axle	Spreader System	Spray System	Safety Checks
Before each use	Check engine oil level Check engine rpms to 2800	 Check hydraulic oil level Check Lovejoy coupler for tightness and fit Check hoses and fittings for leaks Check drive Check drive 	 Check tire pressure Check lug nuts for proper tightness Check for tire wear Check and confirm cotter pins are in place 	 Inspect cotter pin Inspect all pivot point hardware 	• Inspect cotter pin	 Check impeller condition Clean impeller Check spreader on/off cable Check and clean material diverter Check impeller Speed Check agitator 	 Check and clean the nozzle screens located in the spray nozzle bodies. Check and clean in-line filter Check spray wand hose condition Check hoses and fitting for leaks 	 Verify all safety and warning labels are in place
After initial 20 hours	Change engine oil Check air filter			 Inspect and tighten castle nut 	 Inspect and tighten castle nut 			
Every 50 Hours			 Grease front wheel hubs 	 Grease pivot point 				
Every 100 Hours	Change engine oil			 Inspect and tighten castle nut 	 Inspect and tighten castle nut 			
Every 300 Hours	 Change air filter Check spark plug 							
Every 500 Hours		 Change hydraulic oil Change hydraulic oil 	Repack and adjust front wheel bearings					

Specifications - Model TR360

Hopper Capacity	250 lbs. fo	r Single Hoppe	r 125/	125 lbs. for Dual Hopper
Spray Tank Capacity	20 gals Spray cove	ərage 80 M sq.	ft. per tank	
Honda GX390	13 hp, Red	coil and Electric	: Start, 18 Amp	built in charging system, Full day run on fuel tank
	Hydro-Gea	ar Hydraulic Co	mponents	
	Electric on	demand REM	CO 5.3 gal per	minute spray pump
	Electric on	l demand hopp	er agitation	
Unit weight (empty)	620 lbs.			
Weight distribution	Ę	FR	RL	RR
	140 lbs.	140 lbs.	149 lbs.	153 lbs.
Fully loaded with 250 lbs. plus 20 gal	302 lbs.	302 lbs.	175 lbs.	190 lbs.
Ground Speed	4.5 mph m	lax recommenc	led	
Application Speed	3564 sq. ft	/minute on flat	t turf	
Spread Width	9' Split ho	pper capability		
Spray Width – wide	9' On der	nand push butto	on control	
Spray Width – narrow	4.5' Spot	spray extensior	hose – nozzle	
Spray Width Wand	Spot spray	/ extension hos	e - nozzle	

Spraying Systems Nozzle Selection Rates

TEEJET NOZZLE	PSI	DROP SIZE	CAPACITY ONE NOZZLE IN GPM	CAPACITY ONE NOZZLE IN OZ / MIN	PER NOZZLE RATE GPA 4.0 MPH	PER NOZZLE RATE GPA 5.0 MPH	PER NOZZLE RATE GPA 6.0 MPH
TF VS 2.0	20	хс	0.28	36	10.4	8.3	6.9
	30	XC	0.35	45	13.0	10.4	8.7
	40	VC	0.40	51	14.9	11.9	9.9
TF VS 2.5	20	UC	0.35	45	13.0	10.4	8.7
	30	xc	0.43	55	16.0	12.8	10.6
Standard Installed	40	хс	0.50	64	18.6	14.9	12.4
TF VS 3.0	20	ПС	0.42	54	15.6	12.5	1.4
	30	XC	0.52	67	19.3	15.4	12.9
	40	XC	0.60	77	22.0	17.8	14.9
TF VS 4.0	20	ПС	0.57	73	21.0	16.9	14.1
	30	xc	0.69	88	26.0	20.0	17.1
	40	XC	0.80	102	30.0	24.0	19.8
TF VS 5.0	20	ПС	0.71	91	26.0	21.0	17.6
	30	NC	0.87	111	32.0	26.0	22.0
	40	XV	1.00	128	30.0	30.0	25.0
TF VS 7.5	20	ПС	1.06	136	39.0	31.0	26.0
	30	NC	1.30	166	48.0	39.0	32.0
	40	XC	1.50	192	56.0	45.0	37.0

	>
- 61	5
	æ
	4
	8
	2
	0
	c
	-
	5
	0
	~
	5
	٩
	-
	Э
	ь
	ш

Application Calibration Rates

Calibration suggestions are based on known basic standards of use. Each operator MUST calibrate the machine to his/her condition of use. Operator ground speed, engine rpm, spray system pressure level, spread application pass width, terrain traveled, ground moisture, and wind conditions affect the rate of application for both granular and liquid applications.

All spreaders must be calibrated to real use conditions. The recommended method of calibration fine tuning is to use the products over a measured area and determine the actual rate of application.

Granular: With all factory settings in place, the granular scale for application will deliver roughly the number of pounds product (215 –240 SGN) per thousand square feet as displayed on the rate scale.

To Verify Your Use Rate:

apply over a flat turf area and measure the total square feet covered with the full amount of product. Calculate your rate of application Measure 1000 square feet and determine the rate of application upon use. <OR> With a known quantity of product (50 lbs.), and adjust accordingly.

Liquid: With all factory settings in place, the liquid rate of application will remain roughly 32 fluid ounces per 1000 square feet of turf grass area.

To Verify Your Use Rate:

Capture the liquid from the nozzle for a one-minute period of time. Operate your machine in a straight line under your conditions over a one-minute period of time. This will provide the known total liquid coverage rate of application for your machine.

Average Your Rates

Measure the area treated by your machine using known quantities of both liquid material sprayed and granular material applied. Average this calculation over various areas. Or, check your use rate after several lawns or areas are treated throughout the day. This will ensure that the applicator knows the rates of application used throughout the day and can make the fine turned adjustments as needed

EVERY OPERATOR APPLIES PRODUCT DIFFERENTLY. MAKE SURE THE MACHINE OPERATOR VERIFIES THEIR PERSONAL USE RATES ON AN ONGOING BASIS. EVERY DAY IS DIFFERENT.

Turfware Equipment Company – Safe Work Procedure 360 RIDE-ON Spreader/Sprayer

DO NOT use this machine unless you have been instructed in its safe use and operation and have been given permission

THIS PERSONAL PROTECTIVE EQUIPMENT MUST BE WORN

PRE-OPERATIONAL SAFETY CHECKS

- Locate and ensure you are familiar with all machine operations and controls.
- Ensure all guards are fitted, secure and functional. Do not operate if guards are missing or faulty.
- Ensure that all warning labels are in place and in sound condition.
- Ensure any pneumatic and hydraulic mechanisms are in sound condition.
- Ensure all electrical switches are functioning.
- Ensure the engine area is clear of all debris, fuel and grease before using.

OPERATIONAL SAFETY CHECKS

- Be sure the parking brake is engaged prior to starting the machine.
- Keep clear of moving machine parts.
- Drive at a speed slow enough to keep control over unexpected hazards.
- Travel up/down slopes rather than across, taking extra care when ascending or descending steep slopes.
- Take care when refuelling to avoid spilling fuel onto hot motor or exhaust.
- Before making adjustments, bring the machine to a complete standstill and engage the parking brake and turn off the engine.
- Watch for ejected material. Ensure no person or animal is endangered when operating equipment.

ENDING OPERATIONS

- Park on even ground.
- Lock the parking brake.
- Stop the engine and remove the key.
- Turn the fuel valve to the CLOSED or OFF position.

CLEANING UP

- Remove any foreign material from in and around engine and catcher parts.
- Check that all fasteners are properly installed to ensure that the TR360 is in safe operating condition.

POTENTIAL HAZARDS AND INJURIES

- Rapidly rotating impeller.
- Noise and heat.
- Pinch point.
- Ejected material and flying debris.

DON'T

- Do not use faulty equipment. Report suspect machinery immediately to your supervisor.
- Never carry passengers.
- Never allow anyone near the machine while in operation.
- Never operate this machine on slopes exceeding 20 degrees in any direction

This SWP does not necessarily cover all possible hazards associated with this equipment and should be used in conjunction with other references. It is designed as a guide to be used to compliment training and as a reminder to users prior to equipment use.

Purchase Date

Model Number

Serial Number

© 2018 Turfware. All rights reserved Phone: 330-929-9000 • 1-800-637-4000

Turfware Equipment Company • 1049 McCauley Road • Stow, Ohio 44224